

Instruction Guide

Multi-Purpose Spill Kit

Reorder # 15201 (Poly Bag)



What's Included:

- 15 oz. Acid Lock Solidifier
- 15 oz. Alky Solidifier
- 15 oz. Green-Z® Solidifier
- 8 oz. Petro Lock Absorbent
- Caution Tape Roll
- 3 Clear Disposal Bags (30" x 37")
- D.O.T. Incident Report Tag
- Drop Cloth
- Instructions
- Pair of Nitrile Gloves
- Respirator
- 3 Scoop/Scrapers
- 3 Twist Ties
- Vented Goggles
- Zammie® Sewer Stopper (15" x 21")



Scan here to view the instruction video!



Step 1: Caution Tape

Step 1: Put out Caution Tape Roll.



Step 2: Gloves

Step 2: Put on Nitrile Gloves.



Step 3: Goggles

Step 3: Put on Vented Goggles.



Step 4: Respirator

Step 4: Put on Respirator.



Step 5: Choose Solidifier

Step 5: Flip the page to view the solidifier descriptions and choose the one that best fits your spill.



Step 6: Solidifier

Step 6: Sprinkle Solidifier over the spill. Allow liquid to congeal for safer handling and transport.



Step 7: Scoop & Scaper

Step 7: Collect and remove gelled material with Scoop/Scaper.



Step 8: Clear Disposal Bag

Step 8: Place hazardous materials along with Nitrile Gloves, Vented Goggles, Respirator and Scoop/Scaper into Clear Disposal Bag.



Step 9: D.O.T. Tag & Twist Tie

Step 9: Use Twist Tie to securely close Clear Disposal Bag and attach D.O.T. Incident Report Tag. Dispose according to local, state, and federal regulations.

Rev 25.11

Instruction Guide

Multi-Purpose Spill Kit

Reorder # 15201 (Poly Bag)



Step 5: Choose Solidifier



Acid Lock

Safetec's Acid Lock Fluid Control Solidifier is a specialized solution designed for the safe and effective solidification of **Acidic liquids**. This powerful formula swiftly transforms and neutralizes low pH spills into a gel-like substance, such as **Acetic Acid, Hydrochloric Acid, Nitric Acid, and Sulfuric Acid**, into a gel-like substance.



Alky

Safetec's Alky Fluid Control Solidifier is engineered to swiftly neutralize and solidify **high pH spills**, including **Ammonium Hydroxide, Sodium Hydroxide, and Potassium Hydroxide**. This potent formula rapidly transforms these challenging spills into a manageable, gel-like substance.



Green-Z®

Experience effortless and efficient **infectious or hazardous waste** cleanup with Safetec's Green-Z® Solidifier. Ideal for medical settings, the shaker top ensures a quick and uniform distribution of the solidifier over spills, facilitating a prompt response to minimize potential harm or contamination. The controlled application not only reduces waste, but Green-Z® does not contain chlorine, making it a safe option for the cleanup of certain **chemicals**.



Petro Lock

Safetec's Petro Lock Fluid Control Solidifier is your trusted solution for rapidly absorbing **petroleum-based spills**, including **Gasoline, Solvents, Crude Oil, and Paint Sludge**. This efficient formula swiftly tackles these spills, transforming them into a manageable, solid substance.



Red Z®

Experience effortless and efficient infectious **blood or body fluid waste** cleanup with Safetec's Red Z® Solidifier in a Shaker Top Bottle. Not only does it provide a crucial safety measure to keep healthcare workers and patients safe, but it also **contains chlorine** to deodorize smells.

Rev 25.11