



Scan the QR code to learn how to use the Formaldehyde Spill Kit.

Scan the QR code to learn how to use the Glutaraldehyde Clean-Up Kit.

**Each Formaldehyde Spill Response Kit contains:**

- 11 oz. bottle of FSC-1 solidifier
- Nitrile gloves
- Vented goggles
- Scoop/scrapper (4)
- Respirator
- Wiper pads (3)
- Open backed gown
- 30 gallon bags (4)



**FSC-1 Formalin Spill Control -**

Aids in reducing exposure to formaldehyde gas by immobilizing formalin and transforming it to an easily removed semi-solid mass. The resulting mass cools rapidly to minimize formaldehyde off-gassing.

\*FSC-1 capacity to convert and immobilize formalin decreases as the concentration of formalin increases.



**Each Glutaraldehyde Clean-Up Kit contains:**

- 5 oz. bottle of Green-Z® solidifier
- Nitrile gloves
- 2.2 pouch of GPT-1 pouch
- Ventilated goggles
- Glutaraldehyde respirator
- Scoop/scrapper (2)
- 30 gallon bag
- Instructions



**Safetec® Formaldehyde Spill Response Kit & FSC-1**

**Reduces Exposure to Formaldehyde Gas**

A convenient emergency response kit for medical personnel using formalin or other formaldehyde-containing substances. Ideal for containing small-volume spills. (Where a significant volume of fluid must be contained, notify emergency response personnel in accordance with facility guidelines.) Available in highly visible, durable, easy-to-share hard vinyl case. *Refill kits available.*

Order No.	Description	Case Qty.
48630	Formaldehyde Spill Response Kit (Hard Case)	1 Kit cs.
48625	Formaldehyde Spill Response Kit (Kit Refill)	1 Kit cs.
47101	11oz. (0.69 lb. = 311.8 g.) FSC-1 Shaker Bottle	12 Bottles cs.

One 11 oz. Bottle Will Treat...	
Formaldehyde (fl. oz.)	Formaldehyde Solution Strength % (wt.wt.)
9.2 oz. (270.7 mL)	37% Strength
11.4 oz. (337.4 mL)	30% Strength
17.6 oz. (504.5 mL)	20% Strength
23.7 oz. (700.3 mL)	15% Strength
36.7 oz. (1074.1 mL)	10% Strength
92.0 oz. (2720.8 mL)	4% Strength

\*Please Note: Not recommended to be used with 40% formalin or higher.

**Safetec® Glutaraldehyde Clean-Up Kit & GPT-1**

**Reduces Exposure to Glutaraldehyde**

Contains GPT-1 pre-treatment and neutralizer, and Green-Z® fluid control solidifier. Sprinkle GPT-1 over the glutaraldehyde spill. The spill turns brown when it has been neutralized. Sprinkle Green-Z® to turn the neutralized spill into a semi-solid mass.

**Safetec® GPT-1 Glutaraldehyde Pretreatment**

Transforms glutaraldehyde spills to nearly neutral pH. Reduces odor and biocidal activity, rendering solutions more acceptable for the sewer.

Order No.	Description	Case Qty.
19155	Glutaraldehyde Clean-Up Kit (Hard Case)	6 Kits per cs.
19150	Glutaraldehyde Clean-Up Kit (Kit Refill)	12 Kits per cs.
47201	2.2 oz. GPT-1 Glutaraldehyde Pouch	60 pouches per cs.





**Each Chemotherapy Spill Kit contains:**

- Nitrile gloves (2)
- Safety shield
- Open backed gown
- 21g pouch of Green-Z® solidifier
- Scoop & scraper
- Wiper pads (2)
- Super barrier zorb sheet
- Sharps disposal container
- Red bio-hazard waste bag
- Twist tie
- Identification tag
- Instructions



**Each Mercury Spill Kit contains:**

- Nitrile gloves
- Safety shield
- 21g pouch of Green-Z® solidifier (2)
- Scoop & scraper (2)
- Wiper pad
- 4 oz. Absorbent activator bottle
- Zip lock bag
- White disposal bag
- Twist tie
- Instructions



**Safetec® Chemotherapy Spill Kit**

**Protects and Cleans up Spills Involving Cytotoxic Therapy Drugs**

This kit features Green-Z® solidifier to solidify and contain hazardous chemical spills for quick and easy clean-up and disposal with minimal exposure.

Order No.	Description	Case Qty.
48725	Chemotherapy Spill Kit (Poly Bag)	12 cs.



**Safetec® Mercury Spill Kit**

Contains Green-Z® solidifier to encircle and contain mercury. Just pour Green-Z® around the spill then activate it with water, then scoop the contained mercury into the disposal bag and seal.

Order No.	Description	Case Qty.
19100	Mercury Spill Kit (Kit Refill)	24 cs.
19105	Mercury Spill Kit (Hard Case)	12 cs.